





Text Messaging


How to Send a Text Message

1. From Home Screen Menu, select "Messages".
2. Press Menu. 
3. Select "Compose SMS Text".
4. Click the trackball  and select the "phone / email" address you would like to send the message to if "phone / email" has been entered in Address Book. At the top of the list is a **[Use Once]** option that the user can use once (phone / or email) and the phone will not ask you to save the information.
5. Enter the desired number or address (applicable option) and click the trackball .
6. Enter your message and click the trackball .
7. Select "Send".

How to Retrieve a Text Message






When you receive a new text message, your phone will play a notification ring and the message will appear on your screen. (Pending device sound Profile setting)

To review all messages in your text messaging inbox.

1. From the Home Screen Menu, select and click  the option "Messages".
2. All message types will appear in this list.
3. To sort only SMS (Text) messages press ALT + S.


Email

How to Send an Email

1. From Main Screen Menu, select and click  "Messages".
2. Press Menu. 
3. Select "Compose Email".
4. Enter the email address of the intended recipient(s). If multiple addresses separate with a comma (,) and a space between addresses.
5. Scroll with the trackball  to the Subject: line and enter a title.
6. Scroll to the line under the Subject: line and enter your message.
7. Click the trackball .
8. Select  "Send".






Sending A Picture or Video

How to Send a Picture or Video Message to an Email Address

1. Take a picture or video with your BlackBerry device.
2. Once picture or video has been taken select the E-mail Icon. (Name the picture or video for selection purposes, generic name is given to media if no name is given.)
3. Enter the recipient's address.
4. If you would like to include text with the picture, scroll down and enter your message.
5. Click the trackball and select  "Send".

SaskTel BlackBerry Curve 8330 Feature Instructions




How to Send a Picture or Video from Memory

1. From the Home Screen Menu, select and click  "Media".
2. Select "Pictures" or "Videos" from the Media Selection screen, if you do not see the Media Selection screen press  "Back" until you see the icons for the Media selection.
3. Select "My Pictures" or "All Videos", select the picture or video that you took. (You may need to look on a Memory Card if equipped)
4. Highlight the picture or video that you would like to send and press Menu .
5. Scroll down the list and select  "Send As Email". (If this does not appear then the picture or video is in an unsupported format, pictures and videos taken with the BlackBerry are compatible to send via email)
6. Enter the recipient's address.
7. If you would like to include text with the picture, scroll down and enter your message.
8. Click the trackball and select  "Send".

How to Retrieve a Picture or Video Message

When you receive a new picture or video message, your phone will play a notification ring and the message will appear on your screen. (Pending device sound profile settings)
The message will appear as an email and have a paper clip on the email as the Picture or Video will arrive as an attachment.

To review all messages in your picture and video messaging inbox:





1. From Main Screen Menu, select and click  "Messages".
2. Open email with paper clip icon, video or picture will be sent as an attachment.
3. Select Attachment(s) and click the trackball  and select "Open Attachment"
4. Select the file and click the trackball  and file will open on BlackBerry if the picture or video supported by your BlackBerry device.

Downloads





Ring Tones

Ring tones for the BlackBerry Curve must be downloaded from the BlackBerry device. PC downloads are not currently supported.













How to Download Ring Tones on your BlackBerry device

1. From Main Screen Menu, select and click  "Browser"
2. Launch the internet and press Menu  from the menu select **Go to...** select and click  **Home Page (WAP...** browser instead of the **BlackBerry™** Browser (refer to your manual for more details).
3. Select and click  either Ringtones from the categories provided.
4. Choose from one of the three storefronts that support BlackBerry devices:
 1. MuchMusic Store
 2. MTV Store
 3. Sympatico Store
5. Browse the content.








SaskTel BlackBerry Curve 8330 Feature Instructions

6. Click and select and click  the specific content to see content details. Depending on the item you selected, screenshots, user guides, and previews may be available. Content price will always be displayed.
7. Select  **Buy** and then **Download**.
8. A Save File screen will open and you can select and click  either the **device memory** or a **card**. The directory location will be displayed.
9. To find your download, go Main Home Screen Menu and navigate to **Media**, then **Ringtones** or **Pictures**. If you do not see the Media Selection screen press  "Back" until you see the icons for the Media selection.
10. Make the selection for "Ringtones" or "Videos" from the menu select "My Pictures" or "All Videos", select the picture or video that you took. (You may need to look on a Memory Card if equipped)

OR, To Download a Screen Saver from MuchMusic, MTV, Sympatico or Rider Zone:

1. From Main Screen Menu, select and click  "Browser"
2. Launch the internet and press Menu  from the menu select **Go to...** select and click  **Home Page (WAP...** browser instead of the **BlackBerry™** Browser (refer to your manual for more details).
3. Select and click  "Ringtones".
4. Select and click  the store that you would like (ie. MuchMusic Store, MTV Store, Sympatico Store, Rider Zone).
5. Select and click  the Screen Saver you would like to download.
6. Select and click  "Buy Now".
7. Select and click  "Download".
8. Select and click  the location to save the file to.
9. A Save File screen will open and you can select  either the **device memory** or a **card**. The directory location will be displayed.
10. To find your download, go Main Home Screen Menu and navigate to **Media**, then **Ringtones** or **Pictures**. If you do not see the Media Selection screen press  "Back" until you see the icons for the Media selection.
11. Make the selection for "Ringtones" or "Videos" from the menu select and click  "My Pictures" or "All Videos", select the picture or video that you took. (You may need to look on a Memory Card if equipped)

How to Set your Ring Tone












1. From Main Screen Menu, select and click  "Media".
2. Select and click  "Ring Tones". If you do not see the Media Selection screen press  "Back" until you see the icons for the Media selection. Make the selection for "Ringtones"
3. Select and click  "My Ring Tones".
4. Select and click  the ring tone that you would to use.
5. Press Menu .
6. Select and click  "Set As Ring Tone".

SaskTel BlackBerry Curve 8330 Feature Instructions











Screen Savers

Screen Savers for the BlackBerry Curve must be downloaded from the BlackBerry device. PC downloads are not currently supported.




How to Download Screen Savers

1. From Main Screen Menu, select and click  "Browser"
2. Launch the internet and press Menu  from the menu select **Go to...** select and click  **Home Page (WAP...** browser instead of the **BlackBerry™** Browser (refer to your manual for more details).
3. Select and click  "Screen Savers".
4. Select and click  the Screen Saver you would like to download.
5. Choose from one of the three storefronts that support BlackBerry devices:
 - a. MuchMusic Store
 - b. MTV Store
 - c. Sympatico Store
6. Browse the content.
7. Click and select and click  the specific content to see content details. Depending on the item you selected, screenshots, user guides, and previews may be available. Content price will always be displayed.
8. Select and click  **Buy** and then **Download**.
9. Select and click  the location to save the file to.
10. A Save File screen will open and you can select  either the **device memory** or a **card**. The directory location will be displayed.
11. To find your download, go Main Home Screen Menu and navigate to **Media**, then **Ringtones** or **Pictures**. If you do not see the Media Selection screen press  "Back" until you see the icons for the Media selection.
12. Make the selection for "Ringtones" or "Videos" from the menu select  "My Pictures" or "All Videos", select the picture or video that you took. (You may need to look on a Memory Card if equipped)








OR, To Download a Screen Saver from MuchMusic, MTV, Sympatico or Rider Zone:

1. From Main Screen Menu, select and click  "Browser"
2. Launch the internet and press Menu  from the menu select **Go to...** select and click  **Home Page (WAP..** browser instead of the **BlackBerry™** Browser (refer to your manual for more details).
3. Select and click  "Screen Savers".
4. Select and click  the store that you would like (ie. MuchMusic Store, MTV Store, Sympatico Store, Rider Zone).
5. Select and click  the Screen Saver you would like to download.
6. Select and click  "Buy Now".
7. Select and click  "Download".
8. Select and click  the location to save the file to.
9. A Save File screen will open and you can select  either the **device memory** or a **card**. The directory location will be displayed.

SaskTel BlackBerry Curve 8330 Feature Instructions




10. To find your download, go Main Home Screen Menu and navigate to **Media**, then **Ringtones** or **Pictures**. If you do not see the Media Selection screen press  "Back" until you see the icons for the Media selection.
11. Make the selection and click  for "Ringtones" or "Videos" from the menu select  "My Pictures" or "All Videos", select the picture or video that you took. (You may need to look on a Memory Card if equipped)

How to set a Downloaded Screen Saver as the Screen Saver on your phone

1. From Main Screen Menu, select and click  "Media".
2. Select and click  "Pictures". If you do not see the Media Selection screen press  "Back" until you see the icons for the Media selection. Make the selection for "Pictures"
3. Select and click  "My Pictures".
4. Select and click  the screen saver or picture that you would to use.
5. Press Menu .
6. Select and click  "Set As Home Screen Image".

Mobile Browser


How to Access Mobile Browser

1. From Home Screen Menu, Select and click  "Browser"
2. For Web pages press Menu  and select :
 - **Home** (takes you to the SaskTel WAP Browser Home page or BlackBerry web downloads page depending on which default browser is set in the device refer to manual)
 - **Go to...** (takes you to a URL where you can enter a web page destination, select pre-loaded favorites for SaskTel WAP Browser or BlackBerry web downloads page, or to web links that the user has save previously)

(Note: All BlackBerry devices are equipped with two browsers, one is a Mobile browser that will restrict content on a web page to a minimum, and an HTML browser that is able to handle web page requests, however depending on the web page complexity it may not be able to view it on your BlackBerry)

Say & Send

How to Send a Say & Send Message

1. From the Home Screen Menu select and click  "**Phone**"
2. Dial **#8767** on your SaskTel BlackBerry cellular phone.
3. The initial menu will provide you with the option to:
 - press **1** to review all of your messages, or
 - press **2** to send a message.

Note: The first time you access the service there will be an extended greeting with slightly different prompts, but they will remain consistent after you begin using the service.
4. After recording the message:
 - Pay-per-use customers must enter the recipient's 10-digit phone number.

SaskTel BlackBerry Curve 8330 Feature Instructions

- Subscription customers can press **1** to address their message to a phone number or press **2** to use your Say & Send address book.
- 5. Once the message has been addressed, you can simply hang-up and the message will be sent. If you stay on the line, you'll be provided with additional menu options.
 - press **1** to send the message,
 - press **2** to listen to your message,
 - press **3** to add recipients (up to 15 recipient per message),
 - press **#** to re-record the message or
 - press ***** to cancel the message altogether.
- 6. After your message is sent, you can disconnect or return to the main menu to send a new message or review any messages that are waiting for you.

How to Listen and Reply to a Say & Send Message

1. You will receive a text message notification that there is a new message waiting for you. To access the message simply press the **Send** or **Talk** key on your phone or dial #8767.
2. You will hear a welcome message for the service then the Say& Send message will play. If you have multiple messages, they will play in order from the newest to the oldest. You can skip messages by pressing the **#** key.
3. After listening to the message, you'll have the option to:
 - **reply to the message** (press **1** and record/send the same way as creating a new message),
 - **forward the message** to another post-paid SaskTel customer (press **2**),
 - **delete the message** (press **3**),
 - **replay the message** (press **4**), or
 - **receive envelope information** for the message (press **5**).
4. After reviewing your messages, you can disconnect or you'll be taken back to the main menu for the service.

Note: The Say & Send text message notification is always the same. It reads "You have a Say& Send message from **Sender's name** or **Sender's cell phone number**. To listen, press send or call #8767". If you do not delete each text message notification, the next time you receive a Say & Send text message notification, it will appear as a duplicate message. To prevent this from happening make sure you delete the notification messages.

How to Access and Manage your Say & Send Account Online

1. Go to www.sasktel.com.
2. Click on "Mobility" under the "Personal" heading.
3. Click on "Features" – on the left-hand side of the page.
4. Click on "Say & send service".
5. Click on "Manage my Say & Send account" under "Say & Send Support" – Right-hand side of the page.
6. Sign in with your 10-digit cell phone number and your Say & Send password.
7. Now you can listen to and manage your messages, create contacts and distribution lists and change your password.